



[Knowledgebase](#) > [Hardware](#) > [Scanners](#) > [WWS800/850](#) > [WWS800 & WWS850 Freedom scanner: How to eliminate the "leading 0" on UPC scans.](#)

## WWS800 & WWS850 Freedom scanner: How to eliminate the "leading 0" on UPC scans.

Internal User - 2017-04-10 - [WWS800/850](#)

Follow the steps below to eliminate leading 0's from UPC scans. These instructions are for both the WWS800 and the WWS850 scanners.

You will find the barcodes used in these steps on pages 33-34 of the most recent manual. Older version of the manual have slightly different page numbers. If the UPCA Parameter codes are not on page 33-34, look for the section titled UPCA Parameters.

### To remove leading 0's from UPC scans:

1. Scan the **Enter Setup** barcode at the bottom of page 34.
2. In the **UPCA Parameters** section, scan the **Disable** barcode under **Convert to EAN13**.
3. Scan the **Update** barcode at the bottom of page 33.

### Related Content

- [Scanner User Manuals, Programming Reference Guides, Quick Reference Guides, Quick Start Guides \(multiple models\) manual](#)
- [Configure the WWS800/850 to send all UPC-A data to Android or iOS mobile devices](#)