



# WASP PROTECT

Portal > Knowledgebase > Hardware > Scanners > WDI4500 > WDI4500: How to enable reading inverse/negative barcodes

---

## WDI4500: How to enable reading inverse/negative barcodes

Scott Kircher - 2017-09-06 - in WDI4500

There are several User Manual pages with configuration barcodes related to scanning inverse/negative barcodes for the WDI4500 scanner:

1D barcodes: Page 5-59 (PDF page 129)

Data Matrix: Page 5-74 (PDF page 144)

QR Code: Page 5-77 (PDF page 147)

Aztec: Page 5-79 (PDF page 149)

### Related Pages

---

- [WDI4500: User Manual and Quick Start Guide](#)