



# WASP PROTECT

Portal > Knowledgebase > Hardware > WWS450 scanner: Determine the serial number and firmware version

---

## WWS450 scanner: Determine the serial number and firmware version

Scott Kircher - 2017-05-12 - in Hardware

The List Setting configuration barcodes are in section 2.4.3 List the Current Settings, on printed pages 27-29 (PDF pages 39-41) of the User Manual.

Procedure for outputting this information:

1. Launch a program such as Notepad or MS Word to receive the information from the scanner.
2. Scan Enter Setup (bottom of odd-numbered pages).
3. Scan the List Page x configuration barcode. The data is sent immediately. Do not click out of your program from step 1, until all the data is transmitted.
4. Scan Update (bottom of even-numbered pages). If this step is omitted, the scanner is still in Setup mode.

An example list page is below. The serial number is near the end of List Page 1; Ver is the firmware version.

---

Parameter Listing (Page 1)

KV-1.00

Ver:1.12

---

=====

#### Interface Parameters

Interface Type : Remote USB HID (PCAT - US Keyboard)  
Capital Lock OFF, Alphabets Case Sensitive,  
Send Digits Using AlphaNumeric Key Pad, Digit Position - Normal  
KBD Layout - Normal, Shift/Capital Lock - Normal  
Special Keyboard Feature : Apply      Kanji Transmission : Disable  
HID Character Transmit Mode : Batch Processing  
Inter-Function Delay : 0 ms              Inter-Character Delay : 0 ms  
Authentication : Disable              PIN : 0000  
Broadcast Device Name : Enable      Sniff Mode : Enable  
Simple Pairing : Disable

#### Buzzer Parameters

Frequency : 4 KHz                      Duration : Shortest  
Volume : Maximum

#### Scanner Parameters

Scan Mode : Laser Mode              Scanner Time-out : 10 Sec  
Negative Barcode : Disable            Reading Redundancy : No  
Re-read Delay : 400 ms              NO READ Support : Disable  
Good Read LED : Enable              Good Read LED On Duration :  
40 ms  
Memory Scanner : Disable              Memory Data Delay : None  
Auto Power Off : 10 Min              Power Saving Duration : 2 Min  
Transmit Buffer : Enable              Picklist Mode : Disable  
Low Battery Alarm : Enable            Serial Number : BH1000857  
Auto Power Off Ignore ScanMode: Disable  
AIM Code ID: Disable  
Scan Engine Revision : PAAAAC05-001-R00

#### Related Pages

- 
- [Scanner User Manuals, Programming Reference Guides, Quick Reference Guides, Quick Start Guides \(multiple models\) manual](#)