

Wasp

BARCODE TECHNOLOGIES

Portal > Knowledgebase > Hardware > WWS800 or WWS850: How to pair directly to a PC with Bluetooth HID

WWS800 or WWS850: How to pair directly to a PC with Bluetooth HID

Internal User - 2023-01-20 - in Hardware

The "wws800-wws850-hid-bluetooth-with-pin.pdf" document is for pairing a WWS800 or WWS850 via Bluetooth HID to Windows, Mac, or Android using a PIN code. (This scanner model is not known to pair with iOS devices such as iPad and iPhone.) This method should work for all versions of Windows, and is a more reliable method than not using a PIN.

<https://dl.waspbarcode.com/kb/scanner/wws800-wws850-hid-bluetooth-with-pin.pdf>

The "wws800-wws850-hid-bluetooth-without-pin-windows-xp.pdf" document is for setting up the WWS800 or WWS850 with a Windows BT adapter in HID mode without a PIN. This will typically only work in Windows XP.

<https://dl.waspbarcode.com/kb/scanner/wws800-wws850-hid-bluetooth-without-pin-windows>

[-xp.pdf](#)

Both documents assume you have our Wasp Bluetooth adapter (note: this is not the same as the WWS800 or WWS850 charging base station). If you are using a different internal or external Bluetooth adapter or device, your experience may vary slightly.

Related Pages

- [Scanner User Manuals, Programming Reference Guides, Quick Reference Guides, Quick Start Guides \(multiple models\) manual](#)
- [WWS800 or WWS850: How to pair directly to a PC with Bluetooth SPP](#)
- [Configure the WWS800/850 to send all UPC-A data to Android or iOS mobile devices](#)