



WASP PROTECT

Portal > Knowledgebase > Hardware > WWS800 or WWS850 scanner: Determine the serial number and firmware version

WWS800 or WWS850 scanner: Determine the serial number and firmware version

Scott Kircher - 2017-05-12 - in Hardware

The List Setting configuration barcodes are on printed page 3 (PDF page 4) of the Reference Guide (manual with configuration barcodes).

Procedure for outputting this information:

1. Launch a program such as Notepad or MS Word to receive the information from the scanner.
2. Scan Enter Setup (bottom of even-numbered pages).
3. Scan the Page x configuration barcode. The data is sent immediately. Do not click out of your program from step 1, until all the data is transmitted.
4. Scan Update (bottom of odd-numbered pages). If this step is omitted, the scanner is still in Setup mode.

An example list page is below. S/N is the serial number; Ver is the firmware version.

Parameter Listing (Page 1)
Ver:5.52

S/N : AG1002220

=====
=====

Interface Parameters

Interface Type : Keyboard Wedge (PCAT - US Keyboard)
Capital Lock OFF, Alphabets Case Sensitive, ALT Composing
Disable,
Send Digits Using AlphaNumeric Key Pad, Digit Position - Default,
KBD Layout - Default, Shift/Capital Lock - Default,
Inter-Character Delay 0 ms RF Auto-Off : 10 min
Power Save Mode : Enable
Memory Scanner : Disable Memory Data Delay : No
Transmit Buffer : Disable

Buzzer Parameters

Frequency : 4 KHz Buzzer Disabled : No

Scanner Parameters

Scan Mode : Laser Mode Scanner Time-out : 10 Sec
Negative Barcode : Disable Reading Redundancy : No
Re-read Delay : 400 ms

Related Pages

- [Scanner User Manuals, Programming Reference Guides, Quick Reference Guides, Quick Start Guides \(multiple models\) manual](#)