

Wasp

BARCODE TECHNOLOGIES

[Portal](#) > [Knowledgebase](#) > [Hardware](#) > [B1000: Can't connect using crossover cable](#)

B1000: Can't connect using crossover cable

Max Holden - 2017-04-10 - in [Hardware](#)

On your clock, press Menu, then enter your code / fingerprint if required.

Select Options > Com Opt > then look at the Net Speed option.

Make sure you have your clock set to 10M-F (10 Mbps - Full duplex). Some network adapters will have an easier time negotiating with the clock at this speed setting.