MASIS BARCODE TECHNOLOGIES

Portal > Knowledgebase > Hardware > POS Equipment > I need to change some of the characters that are transmitted when I swipe a credit card. I would like the scanner to substitute one character for another like when a ? is scanned I need it change rd to %

I need to change some of the characters that are transmitted when I swipe a credit card. I would like the scanner to substitute one character for another like when a ? is scanned I need it change rd to %

Internal User - 2017-04-10 - in POS Equipment

There is no way for the Wasp POS keyboard unit to substitute any characters. The unit can only add additional characters.