



[Knowledgebase](#) > [Hardware](#) > [Scanners](#) > [WDI4500](#) > [WDI4500: How to enable or disable the ability to scan programming barcodes in the User Manual.](#)

## WDI4500: How to enable or disable the ability to scan programming barcodes in the User Manual.

Sicaro - 2023-01-20 - [WDI4500](#)

In order to scan programming barcodes in the WDI4500 Users Manual, the scanner must have parameter scanning enabled. Normally, parameter scanning is only disabled to prevent users from modifying saved configurations. These barcodes are also found in *Chapter 2 - Interface Setup* in the **Wasp WDI4500 Users Manual**.

### WDI4500 Parameter Scanning Barcodes:

<https://dl.waspbarcode.com/kb/scanner/WDI4500ParameterScanning.pdf>

**To Disable Scanning Parameter Barcodes (including the Set Defaults parameter barcodes):** Scan the **Disable Parameter Scanning** barcode.

**To Enable Scanning Parameter Barcodes:** Scan the **Enable Parameter Scanning** barcode.

## Related Content

- [Scanner User Manuals, Programming Reference Guides, Quick Reference Guides, Quick Start Guides \(multiple models\) manual](#)