WPL612: how to mount a 1-inch core roll of labels

Scott Leonard - 2025-01-07 - Printers

The supply spindle in the WPL612 is 1-3/8 inches wide, preventing mounting of a label roll that has a 1-inch core. How to allow this?

You'll need a #2 Phillips-head screwdriver.

1. Remove the screw from the front of the spindle.

2. Remove the back screw, from the right side. The nut on the left is welded to the shroud, so it won't get lost.

3. Slide the shroud piece down to remove it.

4. To prevent loss of the screws, if you like, screw the back (long) screw into the shroud, and the front (short) screw into the spindle.

This allows mounting of smaller-core rolls (down to about 3/4 inch) onto the supply spindle.