WWS450 sends unwanted control characters and/or repeated Enter characters

Scott Leonard - 2023-01-23 - in WWS450/450H

Symptom

When scanning a barcode, the WWS450 scanner sends control characters and/or repeated Enter characters (where it is necessary to unplug the base station's USB and power cables to get it to stop).

Cause

The barcode being scanned contains special function codes, which the scanner is passing to the PC.

Resolution

Download this file:

https://dl.waspbarcode.com/kb/scanner/wws450-special-keyboard-feature.pdf

Print the file.

Scan Enter Setup, Bypass, Update.