WWS550i & WWS100i: When scanning into Office programs, embedded TAB or ENTER characters are not recognized correctly

Jason - 2025-01-06 - WWS550i

By default, the scanner sends these characters as control-key combinations, which works for most applications. However, Word and Excel do not properly interpret those codes. To have the scanner send the codes in a method the Office applications will recognize, download and print the linked document and scan the Enable HT/CR/ESC output as Tab/Enter/Escape barcode.

If you need to turn this function back off, scan the Disable barcode.

WWS550 Function Characters:
https://dl.waspbarcode.com/kb/scanner/wws550i/WWS550-function-characters.pdf