

Wasp



BARCODE TECHNOLOGIES

[Portal](#) > [Knowledgebase](#) > [Hardware](#) > [Scanners](#) > [WWS800/850](#) > [WWS800 series scanner serial cable](#)

WWS800 series scanner serial cable

Scott Leonard - 2017-06-22 - in [WWS800/850](#)

The WWS800 series scanner's serial/RS232 cable has a female DB9 serial plug at one end (goes to PC) and a male HD15 plug at the other (goes to cradle/base station). The serial pinouts are standard serial signals, and they are connected to the HD15 plug as follows:

| HD15 | DB9 |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|  |  |

| | |
|----|-------|
| | 1 |
| 4 | 2 TXD |
| 2 | 3 RXD |
| | 4 |
| 15 | 5 GND |
| | 6 |
| 3 | 7 |
| 1 | 8 |
| 6 | 9 |