

Wasp

BARCODE TECHNOLOGIES

[Portal](#) > [Knowledgebase](#) > [Hardware](#) > [Mobile Computers](#) > [Adding a security certificate to a mobile device for use with the Summit Client Utility](#)

Adding a security certificate to a mobile device for use with the Summit Client Utility

Scott Leonard - 2018-10-12 - in [Mobile Computers](#)

Connect the device with the USB cable, then view its file system with Windows Mobile Device Center (or ActiveSync on Windows XP).

WMDC: File Management, browse the contents of your device

ActiveSync: Tools menu, Explore Pocket PC, My Windows Mobile-Based Device

Find the Certs folder at the path below. Note: If your Summit folder doesn't contain a Certs folder, you will need to create it.

Windows Mobile/Embedded (HC1, WDT60): Windows\Start Menu\Programs\Summit\Certs

Windows CE (WDT90): Windows\Programs\Summit\Certs

Copy your certificate file to the Certs folder. There is also a Readme file here with info (reproduced below).

This directory is the default directory for digital certificates and protected access credentials (PACs) used in conjunction with Extensible Authentication Protocol (EAP) types.

When you use PEAP or EAP-TLS, you must provision a certificate authority (CA) certificate for the EAP authentication server and distribute that certificate to every client device. On the device, you can store the certificate in the Microsoft certificate store or in the directory with the path specified as the value for Certs Path on the Summit Client Utility (SCU) Global window. When you don't specify a Certs Path value, SCU uses the path to this directory for the Certs Path value.

When you enter a CA certificate name on an SCU Credentials page, you enter only the filename and extension, not the path. The Certs Path global setting provides the path.

If you import CA certificates into the Microsoft certificate store and want to use them in SCU, select Use MS store on the Credentials page. When using the Microsoft certificate store, SCU ignores the Certs Path global setting and the value specified in the CA Cert filename field on the Credentials window.

User (not CA) certificates for EAP-TLS must be selected from the Microsoft certificate store.

When you use EAP-FAST, you must create a PAC for each client device. When you create a PAC manually, you must store it in the directory identified by the Certs Path global setting.

More Info in Microsoft's article "Certificates for Windows Mobile 5.0 and Windows Mobile 6":

[https://docs.microsoft.com/en-us/previous-versions/windows/it-pro/windows-phone/cc182301\(v=technet.10\)](https://docs.microsoft.com/en-us/previous-versions/windows/it-pro/windows-phone/cc182301(v=technet.10))

Related Pages

- [Mobile Device User Manuals, Programming Reference Guides, Quick Reference Guides, Quick Start Guides \(multiple models\)](#)
- [Summit Client Utility: How to set up wireless, and choose from multiple SSIDs \(wireless networks\)](#)