



[News](#) > [General](#) > [DISINFECTING RECOMMENDATIONS FOR WASP SCANNERS & MOBILE PRODUCTS](#)

## DISINFECTING RECOMMENDATIONS FOR WASP SCANNERS & MOBILE PRODUCTS

2020-03-20 - Sicaro - [General](#)

### DISINFECTING RECOMMENDATIONS FOR WASP SCANNERS & MOBILE PRODUCTS

To disinfect scanner/device surfaces, Wasp Barcode Technologies recommends using one of the two following solutions:

- Isopropyl Alcohol (70% solution at a minimum)
- Household Bleach (5-6% sodium hypochlorite) - ½ cup bleach diluted in 1 gallon of water

Both options are recommended by the CDC as effective disinfecting solutions. Cleaning procedure is detailed below.

For more generalized information, please visit:

<https://www.cdc.gov/coronavirus/2019-ncov/community/home/cleaning-disinfection.html>

Use a clean paper towel dampened with one of the above solutions to clean and disinfect scan window, display, and exterior surfaces.

### CAUTION

*DO NOT use abrasive cleaning agents or abrasive pads to clean this product. Harsh chemicals, disinfectants, and cleansers can cause damage which will adversely affect scanning and weighing performance. Do not apply bleach solution to any metal including contacts.*