LICASIS BARCODE TECHNOLOGIES

Portal > Knowledgebase > Hardware > Scanners > WWR2900/2905 > WWR2900 series pen scanner: How to scan

WWR2900 series pen scanner: How to scan

Scott Leonard - 2024-04-26 - in WWR2900/2905

Here's a short movie file showing how to scan:

https://dl.waspbarcode.com/kb/scanner/WWR2900scan.MOV

Tips:

- Touch the scanner to the paper/surface.
- Starting placement should be a bit before the barcode starts, and ending placement should be a bit after the barcode ends. This gives the scanner the necessary quiet space.
- Keep the scanning movement quick and constant.
- The scanner should give a single beep at successful read.

This article applies to the WWR2900 series of pen or wand scanner, including WWR2900,

WWR2905, and WWR2950.