

Wasp

BARCODE TECHNOLOGIES

Portal > Knowledgebase > Hardware > InventoryControl: How to change the mobile device's RF/wireless port

InventoryControl: How to change the mobile device's RF/wireless port

Sicaro Burnett - 2023-01-19 - in Hardware

The port the mobile device uses for InventoryControl RF can be changed on the PC to resolve port conflicts for the WaspInventoryWindowsService. When the port is changed, the ServiceInfo.config file on the mobile device must be changed to the new port.

Changing the mobile device's port for InventoryControl RF

1. Connect the device to the pc using the cable.
2. Browse the files on the device using ActiveSync > Explore or Windows Mobile Device Center > File Management > Browse the contents of the device.
3. Look in \Program Files\InventoryControlRF. Copy the file ServiceInfo.config to the PC.

4. Use Notepad on the PC to edit the file. It will currently look like example 1 (the server name and the port number) or example 2 (the server IP address, port number, the server name and the port number)

Example 1:

YOURPCNAME

10005

Example 2:

10.1.7.204

10005

YOURPCNAME

10005

5. Change the port from 10005 to the new port number.

6. After editing the file with your new port, copy the file back to the device with ActiveSync/Windows Mobile Device Center, overwriting the file on the device.

Related Articles:

InventoryControl Error: Mobile device is unable to contact the InventoryControl server through RF

<https://support.waspbarcode.com/kb/articles/570>

Related Pages

- [InventoryControl: Error: "Connection refused. Check if Wasp Inventory Windows Service is started", but the service is started](#)
- [InventoryControl: How to change the port number for the Wasp Inventory Windows Service](#)